

AURORA

Manual

AS1023CD



CROSS-CUT

User Manual for the AS1023CD Aurora Shredder

IMPORTANT!

READ ALL INSTRUCTIONS BEFORE USING

Warranty

Your Aurora shredder is covered by a return to base warranty and in all instances should be returned to your point of purchase for fault rectification.

Aurora warrants all parts of the machine to be free from defects in materials and workmanship for a period of 1 year from the date of the purchase by the original consumer. If any part is found to be defective during the warranty period the sole and exclusive remedy will be the repair or replacement at Aurora's option and expense of the defective part.

Aurora Electronics (UK) Ltd disclaims any liability for incidental or consequential damages attributable to the product. The liability of Aurora Electronics (UK) Ltd is limited to the cost of the repair/replacement of the unit under warranty.

The warranty shall be immediately invalidated if unauthorized repairs or modifications are made, if the machine has been abused or mishandled, if the product has been re-sold, or if the product has not been operated in accordance with the instructions contained in this document.

The warranty is in addition to and does not diminish the consumer's statutory or legal rights.

Thank you for purchasing the AS1023CD Paper Shredder. This product is designed to shred paper and small staples it will also accept small paper clips, credit cards and CD/DVD's. It does not shred adhesive labels, self-seal envelopes, transparencies, fabrics, glossy paper, newspaper, plastic (other than credit cards), cardboard or continuous forms. Please note that using it for these purposes is likely to cause damage and will invalidate your warranty. This paper shredder is not designed to shred large volumes so please refer to the recommended usage capacity quoted below. You may find paper particles in the bin when first opening the shredder this is a result of QC testing procedures.

Recommended Daily Usage = 50 passes per day. (5 minutes on/ 20 minutes off)

Assembly Instructions


Remove all packaging, shredder head and castors.

Turn the lower casing upside down and insert the four castors into the slots, pushing firmly into place.

Fit the shredder head on top of the waste bin and push down firmly to clip into place (there should be no gap between the shredder head and the casing).

If the shredder head is not seated correctly on the casing the "Door Open" indicator will light and the shredder will not operate, even if the bin door is closed.

There is a safety cut out which is activated when the door is open. The shredder will not operate if the door is not closed correctly and the "Door Open" indicator is lit.



Safety Instructions

1. Before use inspect the shredder, mains cable and plug for damage or defects.
2. Locate the shredder away from heat and water sources.
3. Ensure the switch is set to 'off' before connecting to the mains.
4. Always keep ties, loose clothing, jewelry and long hair away from the shredder.
5. Keep children and pets away from the shredder.
6. Disconnect from the mains when not in use or when emptying or cleaning.
7. Do not insert fingers or objects into the shredder at any time.
8. Never attempt to dismantle the shredder for any reason, please return to an authorized service agent for repair or servicing.
9. Never dispose of flammable chemicals or materials that have come into contact with flammable chemicals (for example nail polish, acetone and petroleum) in the shredder bin. Never use flammable oils, petroleum based products or flammable aerosols of any kind in the vicinity of the machine including compressed air dusters.

